

Wireless connection to the projector

Install and start LiveViewer 6

[Installation package](#)

Contact information for the projector

- Projector's remote control - Menu
- -> Network
- -> Wireless Information
- Take up a code or IP

Choose "Enter Passcode" and your wireless connection. Enter projector code and click "Connect".

Projector Connection [X]

Select the option that describes the connection method you would like to use:

- Select From List
- Enter Passcode
- Profile
- History
- Configure Manually
- My Connection (Unregistered)

Please select the network adapter that you are going to use.


Connection Name	Adapter Name
<input type="checkbox"/> Local Area Con...	Intel(R) 82577LM Gigabit N...
<input checked="" type="checkbox"/> Wireless Netw...	Intel(R) Centrino(R) Ultimat...

Please enter the Passcode.


**** - **** - ****

The Passcode is a 12-digit code, that can be found on the Startup Screen of the projector you are currently trying to connect to.


Click "Yes"



Click "Show"



An alternative way of, link IP address.
Choose "Configure Manually" and choose
own WLAN connection.



Choose "wireless" and "Next" OR enter the SSID to "wireless"

Projector Connection [X]

Enter the following information.

SSID : wireless

SSID	MAC address
<input checked="" type="checkbox"/> wireless	
<input type="checkbox"/> eduroam	3CCE7349D892
<input type="checkbox"/> GUEST	18339DF99531

Find

Encryption : OFF

Encryption key :

Mode : AD-HOC

Enter the Wireless Projector Configuration information.
Please refer to the following instruction for wireless setup.
Menu - Advanced Menu - Network - Wireless Information

< Back Next > Exit

Type projector IP, click "Add", type subnet mask like in picture and click "Connect"

Projector Connection [X]

Please select the projector that you are going to connect.

IP address : 192 . 168 . 10 . 254 [Add]


192.168.10.254 [Delete]

Subnet mask : 255 . 255 . 255 . 0


Enter Projector IP Address and Subnet mask.

< Back Connect Exit

Click "Yes"



Click "Show"



- If does not work, try the remote control to the "Search" button and the projector will start to look for different sources of images.